User Manual
AFRA TITAN SAFE
AF-BS4700E

Press the red reset button, you can set the fingerprint, as well as the password; The initial user password is 1234.

Set the user password

1. Press the red reset button, and then enter a password of 1~8 digits (after 8 digits, enter any digit will cover the 8th digit), press the "#" key, and hear two beep;
2. Then enter the password again and press the "#" key.

If you enter the same password twice and hear one beep, the new password is successfully set.
If the two passwords are different, you hear three beep.

Register the fingerprints

Remark: Repeat 5 times during registration, up to 20 fingerprints can be registered
Press the red reset button, then place the finger to be registered in the center on the fingerprint collector, hear the one short beep, remove the finger and press again, repeat 5 times, hear the long beep, fingerprint registration is successful.

Restore factory Settings

Long press and hold the red reset button for 2~3 seconds, the "ERROR" light blinks and starts to delete the distribution information. With the repeat beep, the user password is changed to 1234, and the fingerprints is cleared.
Restore the mode that any fingerprint can open the door.

Use emergency key to open the door

To open the safe for the first time, please use the emergency key.
Press and turn the emergency lock cover count clockwise in the door, then insert the emergency key, and turn it clockwise.
Turn the knob clockwise to open the door.

Use password, fingerprint or combination mode to open the door

Password to open the door: press the “#” key, then enter the correct password, and then press the “#” key to open the door.
Fingerprint to open the door: Put your finger on the fingerprint collector, and you can open the door after successful identification.
Combination mode to open the door: You can open the door after entering your fingerprint and password.
When entering the wrong password or wrong fingerprint, the error light will lit and the buzzer repeat beep. The alarm goes off when 5 times consecutive error.

Mode switch to open the door

Quickly press the red reset button twice, hear repeat beep, it’s set to combination opening mode, that mean need to use both finger and code together to open the door.
Quickly press the red reset button twice, hear two beep, its set to standard opening mode that means use finger or code can open the door.

Vibration alarm

Press "9" key, at the same time all the lights are lit with a beep, the vibration alarm is turned on, and the vibration alarm is turned off every time the door is opened.

Silence mode

Long press the "*" key (about 3 seconds), the light is on, and the sound is turn off.
Long press the "*"key again (about 3 seconds). The light is on, and the sound is turn on.

Under voltage warning

When the power supply voltage is insufficient, when the system exits after use, there’s five short sounds of "beep", please change the batteries on time.